



Using the Belt Sander

1. Wear your protective equipment including ear defenders, dust mask and goggles.
2. Always hold the belt sander firmly with two hands while working.
3. Let the belt sander run up to full speed before lowering it carefully onto the surface. Be prepared for the reactive force when the sanding belt contacts the surface.
4. Keep the cable clear do not let the machine run over it.
5. Apply only moderate pressure to the machine. Any extra pressure will overload the machine and may cause grooves in the work.
6. Lift the machine off the work surface before switching off.
7. If you think the cable may be cut or damaged in any way, switch off and unplug at the socket before inspecting it. If the cable attached to the belt sander is damaged, stop using the machine. Contact the hire company. If an extension cable has been damaged, do not use it again.
8. Take care not to accidentally pull the plug from the socket.
9. Watch out for signs that vibration may be affecting your hands. If your fingers start to tingle or feel numb, take a short break from using the machine. Exercise your fingers to encourage blood circulation. **Find out more about vibration. Ask the hire company for a copy of the HAE leaflet no. 2150 – Hand-arm vibration or visit www.hse.gov.uk/vibration**
10. To help prevent vibration affecting your hands, operate the machine for shorter periods. Keep your hands warm – wearing gloves may help do this.
11. After switching off, do not put the machine down until the belt has stopped moving it.
12. Make sure that any ventilation slots in the belt sander do not get blocked with sawdust.
13. Remember to empty the dust bag when it is half full or when you stop work. Wood dust is highly flammable do not empty the dust bag onto a fire.
14. Switch off and unplug before making adjustments or changing the sanding belt.
15. Switch off and remove the plug from the socket before leaving the belt sander unattended.
16. If your equipment does not work properly do not attempt to repair it. Contact the hire company.
17. You may want to read this leaflet again. Please keep it until you finish work.

Belt Sander

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read all of this leaflet BEFORE you use the Belt Sander

1. Electricity is dangerous and must always be used with great care.
2. This belt sander is designed to sand wood, but not rough timber. It can also be used on metal, rust or painted surfaces. You must use the appropriate sanding belt. It is not designed for any other purpose.
3. The action of this belt sander can cause injury or damage if the machine is not used in a careful and controlled way.
4. If you have not used a belt sander before, familiarise yourself with the machine on some straightforward work before you start on the main task.
5. Plan your work and think ahead to make sure you will always be working safely.
6. You must have at least the following items of personal protective equipment: goggles: EN166 or BS2092; dust mask - a minimum of EN149 FFP3(s) protection; Safety boots to EN345 or BS1870/4972; industrial quality gloves; residual-current device (RCD) if using a 230 volt (mains) supply.
7. A personal first-aid kit should be available.
8. This belt sander must not be used by minors, or by anyone under the influence of drugs or alcohol.
9. This belt sander is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.
10. Although belt sanders are designed for one person operation you should always be careful you do not lift beyond your own capabilities.



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
44 (0) 121 333 4109
Fax: mail@hae.org.uk
Email: www.hae.org.uk
website:

Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Copyright Hire Association Europe April 2011

Summary:

110V: Wall socket > transformer > any necessary extension cable > belt sander.
230V: Wall socket > RCD > any necessary extension cable > belt sander.

1. Use a residual current device (RCD) plugged directly in to the 230volt socket. Plug your machine into the RCD. This will help to protect you against electric shock if the cable or machine gets damaged.

2. Use the "TEST" button to check that the RCD is working each time you use it. Reset the RCD according to the instructions supplied with it.

3. If you need to use an extension cable, follow any special instructions given by the hire company. If the hire company has not given any special instructions, you should only use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the RCD.

4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

5. Make sure that any extension cable connections are dry and safe.

6. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

7. Do not empty the sawdust bag onto a fire or into a highly flammable area.

8. Empty the dust bag when it is half full or when you stop work. Remember the sawdust is highly flammable.

9. Do not empty the sawdust bag onto a fire or into a highly flammable area.

10. Although belt sanders are designed for one person operation you should always be careful you do not lift beyond your own capabilities.

OPERATORS

1. The following items of personal protective equipment (PPE) are the minimum that should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.

2. Sanding certain materials makes a large amount of dust - cover any surfaces or objects that may be damaged, or difficult to clean.

3. The sanding belts must be fitted in the correct direction of rotation as marked on each belt.

4. Adjust the tension and tracking each time you fit a new belt.

5. Empty the dust bag when it is half full or when you stop work. Remember the sawdust is highly flammable.

6. Do not empty the sawdust bag onto a fire or into a highly flammable area.

7. Any work that is not part of a fixture should be securely clamped or held in a vice.

8. Sanding certain materials makes a large amount of dust - cover any surfaces or objects that may be damaged, or difficult to clean.

9. Clear the area of trip hazards such as rubble, rubbish etc.

10. Do not use this sander in the rain or where it might get wet.

11. Any work that is not part of a fixture should be securely clamped or held in a vice.

12. Sanding certain materials makes a large amount of dust - cover any surfaces or objects that may be damaged, or difficult to clean.

13. The sanding belts must be fitted in the correct direction of rotation as marked on each belt.

14. Adjust the tension and tracking each time you fit a new belt.

15. Empty the dust bag when it is half full or when you stop work. Remember the sawdust is highly flammable.

16. Do not empty the sawdust bag onto a fire or into a highly flammable area.

17. Although belt sanders are designed for one person operation you should always be careful you do not lift beyond your own capabilities.

230 VOLT MACHINES (SQUARE PIN OR BLUE PLUG)

1. Use a residual current device (RCD) plugged directly in to the 230volt socket. Plug your machine into the RCD. This will help to protect you against electric shock if the cable or machine gets damaged.

2. Use the "TEST" button to check that the RCD is working each time you use it. Reset the RCD according to the instructions supplied with it.

3. If you need to use an extension cable, follow any special instructions given by the hire company. If the hire company has not given any special instructions, you should only use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the RCD.

4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

5. Make sure that any extension cable connections are dry and safe.

110 VOLT MACHINES (YELLOW PLUG)

1. If you are using a portable transformer, plug the transformer directly into the 230 volt socket. Do not use any 230V extension cables.

2. If you need to use an extension cable, follow any special instructions given by the hire company. If the hire company has not given any special instructions, you should only use a suitably rated heavy duty one, not longer than 50 metres (160 feet).

3. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

4. Do not empty the sawdust bag onto a fire or into a highly flammable area.

5. Empty the dust bag when it is half full or when you stop work. Remember the sawdust is highly flammable.

6. Do not empty the sawdust bag onto a fire or into a highly flammable area.