



Using the Cultivator

1. Wear your protective equipment including ear defenders and boots.
2. Position your cultivator on the area to be dug then swing the transport wheel(s) out of the way and lock them..
3. On some models the transport wheels are removed completely for digging.
4. When positioning the cultivator keep the stationary tines clear of any path or borders or they may cause damage.
5. Usually on these models, the depth gauge, often a single tine, fits into the same clamp after removal of the wheels. Remember to set the depth gauge carefully following the instructions detailed under the heading CULTIVATOR, paragraphs 16 and 17.
6. Always hold the cultivator handle firmly with both hands while working.
7. While digging, keep a lookout for any stones or other objects in your path. Stop the cultivator and clear them out of the way.
8. The rotating tines can throw out small stones or other hard objects. Do not bend down to the tines when they are running.
9. Do not operate the digging tines on concrete or other hard surfaces. Injury or damage may occur.
10. If the tines become clogged with long grass or weeds, you must stop the engine. Clear the tines wearing gloves.
11. If you are working on heavy clay soils, check that there is no build up of clay around the drive mechanism. You must stop the cultivator before you attempt to remove it.
12. While working with the cultivator take care not to lose your footing on the soft uneven ground you have just turned over.
13. Stop the engine before leaving the machine unattended.
14. Clean the machine at the end of each day and before you return it to the hire company.
15. If your equipment does not work properly, do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely as it may be required for future reference



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

- STARTING**
1. This section describes the starting procedure for most cultivators.
 2. Some cultivators have a blade brake that needs to be held in during starting and use. If the hire company has given you special instructions for your cultivator, follow them. Otherwise, follow the instructions given below.
 3. Check that there is no obstruction, including long grass, under the cultivator.
 4. Open the fuel valve by the fuel tank. Your cultivator may also have a primer valve you have to push several times.
 5. Check that the throttle lever is in the START position.
 6. Hold the machine firmly with your left hand, so that it will not move when you pull the starting cord.
 7. With your right hand, pull out the starting cord handle slowly until you can feel that the starter has engaged with the engine. Don't pull it too far, or the cord may break.
 8. Guide the cord back into place so that it recoils correctly.
 9. If the engine did not start, check that there is sufficient petrol, and that the throttle lever is in the correct position. Pull the starting cord again.
 10. In cold weather, you may need to let the engine warm up by gently opening the throttle, before starting work.
- REFUELLING**
1. No smoking.
 2. Stop the engine and let it cool down.
 3. Move the machine away from your work area.
 4. Clean the filler cap and the area around it to prevent dirt falling into the petrol tank.
 5. Use a funnel and clean petrol when refuelling. Do not spill any fuel on yourself or the machine.
 6. Wipe any fuel off the machine.
 7. If you spill any fuel on the ground, carefully dispose of fuel soaked cloth.



Before Starting Work...

1. Do not use this cultivator where there is a danger of explosion. It will ignite fuel from petrol, or gas cylinders.
2. To reduce the risk of serious or fatal injury from breathing toxic fumes, do not run the engine indoors unless you have good ventilation. Ensure that you have proper ventilation when working in other confined areas.
3. Protect other people from the noise or BS1870 / 4972 giving good foot and ankle protection.
4. Make sure the ground you are about to turn over is free of large stones, pieces of wood, lengths of wire or anything else that may interfere with the tines. Wear your gloves to do this.
5. Dig out any big strong weeds, including the roots, by hand and dispose of them.
6. Long grass will bind the tines so it should be cut down to about one or two inches.
7. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever you use this cultivator. Particular jobs or environments may require a higher level of protection.
8. This equipment is likely to cause noise levels up to 88 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
9. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
10. You will need strong gloves to handle any rubbish or debris on the ground.
11. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
12. You will need strong gloves to handle any rubbish or debris on the ground.
13. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
14. You will need strong gloves to handle any rubbish or debris on the ground.
15. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.

- WORK AREA**
1. Do not use this cultivator where there is a danger of explosion. It will ignite fuel from petrol, or gas cylinders.
 2. To reduce the risk of serious or fatal injury from breathing toxic fumes, do not run the engine indoors unless you have good ventilation. Ensure that you have proper ventilation when working in other confined areas.
 3. Protect other people from the noise or BS1870 / 4972 giving good foot and ankle protection.
 4. Make sure the ground you are about to turn over is free of large stones, pieces of wood, lengths of wire or anything else that may interfere with the tines. Wear your gloves to do this.
 5. Dig out any big strong weeds, including the roots, by hand and dispose of them.
 6. Long grass will bind the tines so it should be cut down to about one or two inches.
 7. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever you use this cultivator. Particular jobs or environments may require a higher level of protection.
 8. This equipment is likely to cause noise levels up to 88 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
 9. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
 10. You will need strong gloves to handle any rubbish or debris on the ground.
 11. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
 12. You will need strong gloves to handle any rubbish or debris on the ground.
 13. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
 14. You will need strong gloves to handle any rubbish or debris on the ground.
 15. You must wear safety boots (EN345 or BS1870 / 4972) giving good foot and ankle protection.
- CULTIVATOR**
1. Check your cultivator completely, including engine, control cables and levers, and the digging tines. If anything is found damaged, do not use the cultivator – contact the hire company.
 2. Keep the cultivator in a near upright position when digging or you may spill oil out of the engine.
 3. You can adjust the handle on your cultivator up and down. Make sure that the adjustment-locking device is tight before you start work.
 4. Your cultivator will have a digging depth control. Do not set it to dig any more than 3" to 4" (8cm to 10cm). To dig deeper, each time second and third pass, make a resetting the depth control.
 5. Do not try to dig deeper than 8" or 9" (20cm to 23cm) in total.
 6. On some models, drive is not

v:012017