



Using the Carpet Cleaner

1. Wear protective equipment including ear defenders and gloves.
2. Do not spray water over electrical equipment. This could cause a short circuit, fire and a fatal shock.
3. Do not spray water at anyone – it could be dangerous.
4. Dry hands, switch off and unplug before emptying waste or leaving the machine unattended.
5. Keep everyone, especially young children and animals off the carpet that has just been cleaned until it is dry. It could harm them.
6. When finished work, empty the cleaning solution and refill with clean water. Operate the machine in a safe place to flush the cleaning solution out of the equipment.
7. Keep the cable clear of any sharp edges in your work area.
8. If the cable appears to be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable attached to the carpet cleaner is damaged, stop using the equipment. Contact the Hire Company. If an extension cable has been damaged, do not use it again.
9. Take care not to accidentally pull the plug from the socket.
10. Switch off and remove the plug from the socket before leaving the machine unattended.
11. Switch off and remove the plug, allow the equipment to cool down before emptying.
12. If the equipment does not work properly, do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely as it may be required for future reference



Hae
HIRE ASSOCIATION EUROPE
Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Carpet Cleaner without Heater

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the Carpet Cleaner

1. Plan your work and think ahead to make sure you will always be working safely.
2. Electricity can be hazardous and must always be used with great care.
3. Electricity and water make a very dangerous combination. Keep electrical equipment away from rain and water.
4. The carpet cleaner is designed to clean carpets and upholstery using the appropriate attachments and cleaning solutions.
5. The action of the carpet cleaner can cause injury or damage or both if the equipment is not used in a careful and controlled manner.
6. If you have not used a carpet cleaner before, familiarise yourself with the equipment on some scrap carpet before starting on the main task.
7. The following items of personal protective equipment is the minimum that must be worn when using this equipment: Ear muffs / plugs giving protection at the ear for levels up to 85 dB(A); waterproof gloves; rcd if using 230 volt (mains) supply.
8. This machine must not be used by minors, or by anyone under the influence of drugs or alcohol.
9. The carpet cleaner is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

1. Use a residual current device ("rcd") plugged directly in to the 230 volt socket. Plug your extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, you should only use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the rcd.
2. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.
3. Make sure that any extension cable connections are dry and safe.

1. Use a residual current device ("rcd") plugged directly in to the 230 volt socket. Plug your extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, you should only use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the rcd.
2. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.
3. Make sure that any extension cable connections are dry and safe.

1. If you are using a portable transformer, plug the transformer directly into the 230V socket. Do not use any 230V extension cables.
2. If you need to use an extension cable, you should only use a suitably rated heavy duty 110v extension cable, not longer than 50 metres (160 feet). You must only use an extension cable if the hire company have not given any special instructions, follow any special instructions given by the hire company.

1. If using chemicals or detergents, follow the instructions supplied with them. Use only the recommended detergent.
2. Check the detergent will not make the colours run in the carpet. Wear gloves and dip a piece of clean white cloth into the solution and rub it vigorously over a hidden piece of carpet. If the colour comes onto the cloth, do not continue, contact the hire company.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Copyright Hire Association Europe April 2011

1. Check the equipment, cables, plugs and all equipment. Do not use anything found damaged contact the hire company.
2. Check that the plug on the machine matches the supply. Do not try to force connections or improvise them.
3. Equipment with a cylindrical yellow industrial plug fitted is designed to run off special 110v supply. The hire company operates. Before switching on the carpet cleaner, know how to stop it.
4. Do not use hot water hotter than recommended by the hire company or marked on the cleaning solution container. It will not make the carpet any cleaner but it may shrink or damage it.
5. Do not use the carpet cleaner to vacuum flammable, corrosive or toxic wastes such as petrol or weedkiller.
6. Do not touch electrical switches or plugs unless hands are dry.
7. Check on how the on / off switch operates. Before switching on the carpet cleaner, know how to stop it.
8. Do not use the carpet cleaner to vacuum flammable, corrosive or toxic wastes such as petrol or weedkiller.
9. Do not touch electrical switches or plugs unless hands are dry.
10. Check on how the on / off switch operates. Before switching on the carpet cleaner, know how to stop it.

1. The following items of personal protective equipment (PPE) are the minimum that should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.
2. The equipment is likely to cause noise levels up to 85 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum if the cleaner is going to be used continuously.
3. Always wear waterproof glove to keep hands dry while working.
4. Anybody who is working near to you will also need to wear appropriate personal protective equipment.