



# Using the Floor Saw


1. Wear protective equipment including gloves, goggles, ear defenders and safety boots.
2. Lower and adjust the pointer arm. Position the machine to start the cut.
3. Open the tap and adjust the water flow to the cutting wheel, unless using dry cutting wheels.
4. Make sure the cutting wheel is running at full speed and then lower it carefully onto the surface.
5. If the machine starts to labour, reduce the depth of cut and make two passes.
6. The machine can only cut in straight lines. Do not try to go round corners.
7. Stop the engine if leaving the machine unattended.
8. If the equipment does not work properly do not attempt to repair it. Contact the hire company.
9. You may want to read this leaflet again. Please keep it safely until you finish work.

# Floor Saw

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

## It is important to read all of this leaflet BEFORE using the Floor Saw

1. Plan your work and think ahead to make sure you will always be working safely.
2. If you have not used a floor saw before, familiarise yourself with the machine on some straightforward work before you start on the main task.
3. Petrol is highly flammable. Take care not to cause a fire or explosion.
4. This floor saw is designed to cut concrete, masonry or asphalt floors using the appropriate cutting wheel. It is not designed for any other purpose.
5. The action of this floor saw can cause injury or damage if the machine is not used in a careful and controlled way.
6. The following items of personal protective equipment must be worn: goggles; dust mask - a minimum of FFP3 protection; ear muffs or plugs giving protection to reduce exposure to 87dB(A) at the ear; Safety boots; industrial gloves.
7. A personal first-aid kit should be available.
8. This machine must not be used by young persons, or by anyone under the influence of drugs or alcohol.
9. This floor saw is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.
10. Floor saws are heavy machines, get help if you have to unload it from your vehicle. Do not lift beyond your own capabilities.



Hire Association Europe  
2450 Regents Court  
The Crescent  
Birmingham Business Park  
Soliuhull B37 7YE

Telephone: 44 (0) 121 380 4600  
Fax: 44 (0) 121 333 4109  
Email: mail@hae.org.uk  
website: www.hae.org.uk

Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

v:032017

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Telephone: 44 (0) 121 380 4600  
Fax: 44 (0) 121 333 4109  
Email: mail@hae.org.uk  
website: www.hae.org.uk

Hire Association Europe  
2450 Regents Court  
The Crescent  
Birmingham Business Park  
Soliuhull B37 7YE



©Copyright Hire Association Europe April 2011

1. If the hire company has given any special instructions, follow them. Otherwise, follow the instructions given below. Position the floor saw at the work position before starting the engine.
  2. Check the oil and fuel levels before trying to start the engine.
  3. Switch the ignition switch to the ON position.
  4. Check that the throttle lever is in the IDLE position.
  5. Do not wear gloves when starting the engine. Also, make sure there is no loose clothing or flapping sleeves that could get caught.
  6. Turn the fuel tap to the open position.
  7. Open the choke lever fully, when starting from cold.
  8. Grasp the pull cord firmly and pull upwards and release.
  9. If the engine is now running, shut the choke lever.
  10. Open the throttle lever to the RUN position.
  11. To stop the engine turn the ignition switch to the OFF position and close the fuel supply tap.
  12. Allow the engine to run for a short period to warm up before starting to cut.
- ### STARTING THE ENGINE
1. Move the fuel can to a safe, cool place.
  2. Put all fuel caps back on properly, and then straight away.
  3. If any fuel is spill on clothes, change ground, wipe it up or cover it with soil.
  4. If small amounts of fuel are spill on the fuel soaked cloth carefully.
  5. Wipe any fuel off the machine. Dispose yourself or the machine.
  6. Use a funnel and clean petrol when refuelling. Do not spill any fuel on the diamond wheel unless you are competent to do so. Ask the hire company for HAE leaflet no. 0403 – abrasive wheels.
  7. Make sure the correct type of cutting wheel is used as recommended by the hire company for the material being cut.
  8. Look at the speed (RPM) stated on the label of the cutting wheel being used, and the speed shown on the floor saw. Check that the cutting wheel is certified to a higher speed than that shown on the machine.
  9. When fitting diamond wheels, check the bore size is the same as the spindle diameter. You must also comply with the direction of rotation mark on the wheel.
  10. Abrasive wheels fitted to this floor saw are for cutting on the edge only. Any side pressure could shatter them.
  11. Make sure the guard is in place and adjusted correctly.
  12. Make sure that you understand all of the controls. Before starting the machine, locate the stop button.
  13. No smoking.
  14. Stop the engine and let it cool down.
  15. If possible move the machine away from your work area.
  16. Clean the filler cap and the area around it to prevent dirt falling into the fuel tank.
- ### CUTTING WHEELS
1. Do not fit or change any abrasive or diamond wheel unless you are competent to do so.
  2. Ask the hire company for HAE leaflet no. 0403 – abrasive wheels.
  3. Make sure the correct type of cutting wheel is used as recommended by the hire company for the material being cut.
  4. Look at the speed (RPM) stated on the label of the cutting wheel being used, and the speed shown on the floor saw. Check that the cutting wheel is certified to a higher speed than that shown on the machine.
  5. When fitting diamond wheels, check the bore size is the same as the spindle diameter. You must also comply with the direction of rotation mark on the wheel.
  6. Abrasive wheels fitted to this floor saw are for cutting on the edge only. Any side pressure could shatter them.
  7. Make sure the guard is in place and adjusted correctly.
  8. Make sure that you understand all of the controls. Before starting the machine, locate the stop button.
  9. No smoking.
  10. Stop the engine and let it cool down.
  11. If possible move the machine away from your work area.
  12. Clean the filler cap and the area around it to prevent dirt falling into the fuel tank.
- ### REFUELLING
1. Open the throttle lever to the RUN position.
  2. Turn the fuel tap to the open position.
  3. Do not wear gloves when starting the engine. Also, make sure there is no loose clothing or flapping sleeves that could get caught.
  4. Turn the fuel tap to the open position.
  5. Do not wear gloves when starting the engine. Also, make sure there is no loose clothing or flapping sleeves that could get caught.
  6. Turn the fuel tap to the open position.
  7. Open the choke lever fully, when starting from cold.
  8. Grasp the pull cord firmly and pull upwards and release.
  9. If the engine is now running, shut the choke lever.
  10. Open the throttle lever to the RUN position.
  11. To stop the engine turn the ignition switch to the OFF position and close the fuel supply tap.
  12. Allow the engine to run for a short period to warm up before starting to cut.

1. Check the machine, engine, and all equipment. Do not use anything found to be damaged. Contact the hire company.
  2. Do not use this machine to cut asbestos or materials containing asbestos.
  3. Always hold the floor saw correctly with two hands while working.
  4. The pointer arm can be swung out of the way when not in use. Check and adjust it ready for use.
  5. If dry cutting wheels are NOT used fill the water tank (if fitted) or connect to a continuous water supply; then check that the water flows directly onto the cutting wheel.
  6. Make sure that you understand all of the controls. Before starting the machine, locate the stop button.
- ### FLOOR SAW
1. This equipment is likely to cause noise levels up to 96 dB(A) - wear appropriate protection for this level as a minimum.
  2. Ear muffs or earplugs giving hearing protection for this level as a minimum.
  3. An appropriate dust mask (with a minimum of FFP3 protection) must be worn when in contact with materials that cause dust.
  4. Safety boots must be worn.
  5. Industrial quality gloves must be worn.
  6. Anybody who is working close by will also need to wear identical personal protective equipment.
- ### WORK AREA
1. Make sure that the area is clear and safe.
  2. Do not use this machine where there is a danger of explosion. It will ignite fumes from petrol, or gas cylinders.
  3. Using this equipment indoors or in confined spaces could cause fatal carbon monoxide poisoning. Never use it in domestic premises and only use it in other indoor situations if its suitability and the ventilation required has been fully assessed. Mechanical extraction ventilation will almost always be required.
  4. Check that there are no buried electric cables, gas or water pipes where cuts are going to be made. Consider using a cable and/or pipe detector, ask the hire company for suitable types available.
  5. Ask the hire company for HAE leaflet no.1415 – cable location and signal generator.
  6. Protect other people from the noise and dust. Set up an exclusion zone around the area where the concrete mixer is being used with physical barriers, barrier tape and signs. Keep children and animals away when using this equipment.
  7. Work should stop immediately should anyone, other than those directly assisting with the work, enter the exclusion zone.
  8. Clear the area of trip hazards such as rubble, rubbish etc.
  9. The following items of personal protective equipment (PPE) are the minimum that should be worn whenever using this machine. Particular jobs or environments may require a higher level of protection.