

DeWalt / Elu Flipover Saw

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.



It is important to read all of this leaflet BEFORE you use the Flipover Saw

- Plan your work and think ahead to make sure you will always be working safely.
- Electricity can be hazardous and must always be used with great care.
- The flip-over saw can be set up either as a pull-down mitre saw, or as a sawbench. Do not try to use it in any other way. It can cut wood and similar composite materials using the standard blade.
- Do not use it to cut asbestos or metal.
- You must have at least the following items of personal protective equipment: goggles – impact resistant EN166-B or BS2092 grade 1; dust mask – a minimum of EN149 FFP3(s) protection; ear muffs or plugs giving protection for levels up to 100 dB(A); gloves.
- This machine must not be used by minors, or by anyone under the influence of drugs or alcohol.
- This machine is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.
- If your equipment does not work properly, do not attempt to repair it. Contact the hire company.



Every effort has been made to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/HA/EH/EA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

HAE THE ASSOCIATION EUROPE
Hire Association Europe
2450 Regents Court
The Crescent
Salford Business Park
Salford B37 7YE
Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
Website: www.hae.org.uk



Using the Mitre Saw

- Wear your protective equipment including goggles and ear defenders.
- Move the sawhead to the required angle, lock the mitre location plunger and turn it anticlockwise a quarter turn.
- Move the sawhead to the required angle, lock the mitre location plunger and turn it anticlockwise a quarter turn.
- Engage the mitre cutting depth stop by turning it to the left.
- BEVEL AND COMPOUND CUTS
1. The sawhead can be tilted at up to 45° to the left to allow bevel cuts. This can be done in compound. Note that the depth of cut will be less than that available for straight cross-cuts.
2. Release the bevel clamp handle. This is spring loaded and has a ratchet action which stops rotation when the angle is set.
3. Set the sawhead to the required angle, using the scale on the right hand side of the sawhead pivot.
4. Lock the bevel clamp handle. Use the ratchet mechanism to leave the clamp handle in a horizontal position so that it does not foul when changing mitre angles.
- STANDARD EQUIPMENT
30 tooth TCT blade
Parallel fence
Push stick
Sliding table
Adjustable stand
Guide rods
Dust extraction stop
Dust extraction kit

Please store this leaflet safely. It may be required for further information

HAE THE ASSOCIATION EUROPE
Hire Association Europe
2450 Regents Court
The Crescent
Salford Business Park
Salford B37 7YE
Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
Website: www.hae.org.uk

PREPARING FOR TRANSPORT
1. The flip over saw is the best transported in saw bench mode. Read the instructions for how to change mode.
2. Make sure that the push stick and any accessories are safely stored with the saw before transporting it.

MITRE SAW TO SAWBENCH
1. Turn the saw.
2. Set the sawhead into the O° straight cross-cut position. Lock the mitre location plunger, located, and the turntable clamp secured.
3. Slacken the riving knife clamp enough to allow the riving knife to swing down and slide across into position behind the blade. Turn the sawblade by hand to check that the riving knife is clear of the blade, and then tighten the clamp knob.
4. Check that the mitre depth stop is turned to the right to disengage.
5. Pull down the sawhead then unclip the rise and fall adjuster from its parked position. Bring the saw blade and riving knife back to the table to a suitable cutting height through the table to a suitable cutting height.
6. If required, fit the rip fence to the table.
7. If required, fit the riving knife.
8. Push the sawblade and riving knife together to ensure they are properly aligned and then tighten the riving knife clamping bolts.
9. Push the sawblade and riving knife together to ensure they are properly aligned and then tighten the riving knife clamping bolts.

MITRE CUTS
1. Tilt the sawhead to make mitre cuts at any angle up to 45° left or right and at straight cross-cut positions. The depth of cut is limited at positions right and left.
2. Release the turntable clamp. Lift the turntable location plunger and turn it anticlockwise a quarter turn.

BEVEL AND COMPOUND CUTS
1. The sawhead can be tilted at up to 45° to the left to allow bevel cuts. This can be done in compound. Note that the depth of cut will be less than that available for straight cross-cuts.
2. Release the bevel clamp handle. This is spring loaded and has a ratchet action which stops rotation when the angle is set.
3. Set the sawhead to the required angle, using the scale on the right hand side of the sawhead pivot.
4. Lock the bevel clamp handle. Use the ratchet mechanism to leave the clamp handle in a horizontal position so that it does not foul when changing mitre angles.

STANDARD EQUIPMENT
30 tooth TCT blade
Parallel fence
Push stick
Sliding table
Adjustable stand
Guide rods
Dust extraction stop
Dust extraction kit

OPERATIONAL SAFETY
1. Do not attempt to sweep away sawdust or debris while the saw is on. Switch off, and let the blade stop first.
2. Make sure that the machine ventilation slots do not become blocked with dust or debris.
3. Do not become blocked with dust or debris.
4. Unplug the machine before changing mode or making any major adjustments.

BEFORE STARTING WORK...
1. Check that you have a proper push stick with the saw, ready for use.
2. You will need a proper gripping or clamping tool if you are going to cut round section timber.
3. Sawdust is flammable and can present a risk of explosion – dispose of it carefully. Never put it onto a fire.
4. Make sure that you understand all of the controls. Before you switch the saw on, you must know how to switch it off.

ELECTRICAL SAFETY 230 VOLT MACHINES
1. A residual current device (‘rCD’) plugged directly into the 230 volt socket. Plug your machine into the rCD.
2. This will help to protect you against electric shock and electric fire hazards on the 230V cable.
3. Use the ‘TEST’ button to check that the rCD is working each time you use it. Reset the rCD according to the instructions supplied with it.
4. If you need an extension cable, you must use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the rCD.
5. Lay the extension cable out carefully avoiding liquids, sharp edges,

doorways or windows where it might get trapped, and places where vehicles might run over it. If you are in a hurry or it will overheat and could catch fire.
6. Make sure that any extension cables connectors are dry and safe.
7. If you are using a portable transformer, plug the transformer directly into the 230 volt socket. Do not use any 230V extension cables.
8. If you need an extension cable, you must use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it into the transformer.
9. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways or windows where it might get trapped, and places where vehicles might run over it. If you are in a hurry or it will overheat and could catch fire.
10. If you need an extension cable, you must use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it into the transformer.

USING THE SAWBENCH
1. Make sure that any extension cable connections are dry and safe.
2. Wear your protective equipment including goggles and ear defenders.
3. Pay attention to the work, and always be prepared for unexpected movement of the material being cut.
4. Let the blade run up to full speed before feeding the wood onto the blade. Do not force it – this will not result in a faster cut.
5. As the trailing edge of a larger sheet of material approaches the blade, the push stick will be pulled away from the blade. It has cleared the riving knife at the rear of the blade.
6. Keep both hands clear of the blade at all times.

SAWBENCH TO MITRE SAW
1. Plugging the saw.
2. Plugging the saw. Plug the guard by pulling the plunger knob on the blade guard to release the guard from the riving knife. Store the guard safely, together with the push stick, they will be essential when the flip-over saw is used as a sawbench.
3. Remove the rip fence and mitre fence, if fitted.
4. Pull the table release lever to the left, then lift the rear of the table and swing it right over until it locks into position at the front.
5. Partially lower the saw head, and disengage the lower end of rise and fall adjuster from its support at the rear of the sawhead. Swing the adjuster upwards until it clips into place in its newly upright position. Let the sawhead rise back into normal position.
6. Push the riving knife clamp knob to allow the riving knife to be tilted to the left and then swing up into the guard away from the blade. Tighten the clamp knob.

WORK AREA
1. Make sure that the area is clear and safe and that the ground is level and solid. There must be no tripping hazards, and adequate lighting. There should be no one near to you or other distractions.
2. Do not use this saw in the rain, or where it might get wet.
3. Do not use this saw where there is a danger of explosion. It will ignite fumes from petrol or gas cylinders.
4. Protect other people from the noise, dust and hazard. Warn others to keep away, put up signs, or barriers around your work area.
5. The following items of personal protective equipment (PPE) are the minimum which should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.
6. You must wear impact resistant goggles (EN166-B or BS2092 grade 1) whenever you use this saw bench.
7. This equipment is likely to cause noise levels up to 100 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for levels up to 100 dB(A).
8. Dust from softwood, hardwood and composite materials can be hazardous to health wear an appropriate dustmask (with a minimum of EN149 FFP3(s) protection) when you are cutting any material that causes dust.
9. Anybody who is working near to you will need to wear the same safety equipment. Make sure you have no loose or flapping clothing that could get caught in the saw.

FLIPOVER SAW
1. Check your flip-over saw, including guards, switches and cables. If anything is found wrong do not use the machine; contact the hire company.
2. Check that the plug on your machine matches your socket. Do not try to force connections or improvise them.
3. Machines with a cylindrical yellow industrial plug fitted are designed to run off a special 110V supply. The hire company will have provided a portable transformer if you need to power the machine from a normal mains 230V supply. If a portable transformer has been supplied, take care not to injure yourself when moving it about – it may be heavier than you think. Machines designed to run directly from 230V mains will have either a normal square pin plug fitted, or a three pin industrial plug around 26kg (60lb) – be careful when you are moving it into position. You may need two people to do this.
4. To fit the legs, place the machine on a bench or strong table. Pull the machine forward and fit each leg in turn, making sure that the clamping wing nut is done up securely.
5. The saw is normally transported in saw bench mode. Read the instructions on changing from sawbench to mitre saw if you plan to set it up as a mitre saw.
6. If you plan to cut sheets of wood or composite material that are larger than the sawtable, you will need an assistant. Use a stable extension – contact the hire company if one has not been supplied.
7. Check that any cable extensions, fences and cutting guides are properly fixed in

USEFUL REFERENCE POINTS
www.hae.org.uk/businessguard

BEFORE STARTING WORK...
1. Check that you have a proper push stick with the saw, ready for use.
2. You will need a proper gripping or clamping tool if you are going to cut round section timber.
3. Sawdust is flammable and can present a risk of explosion – dispose of it carefully. Never put it onto a fire.
4. Make sure that you understand all of the controls. Before you switch the saw on, you must know how to switch it off.

ELECTRICAL SAFETY 230 VOLT MACHINES
1. A residual current device (‘rCD’) plugged directly into the 230 volt socket. Plug your machine into the rCD.
2. This will help to protect you against electric shock and electric fire hazards on the 230V cable.
3. Use the ‘TEST’ button to check that the rCD is working each time you use it. Reset the rCD according to the instructions supplied with it.
4. If you need an extension cable, you must use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the rCD.
5. Lay the extension cable out carefully avoiding liquids, sharp edges,

doorways or windows where it might get trapped, and places where vehicles might run over it. If you are in a hurry or it will overheat and could catch fire.
6. Make sure that any extension cables connectors are dry and safe.
7. If you are using a portable transformer, plug the transformer directly into the 230 volt socket. Do not use any 230V extension cables.
8. If you need an extension cable, you must use a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it into the transformer.

USING THE SAWBENCH
1. Make sure that any extension cable connections are dry and safe.
2. Wear your protective equipment including goggles and ear defenders.
3. Pay attention to the work, and always be prepared for unexpected movement of the material being cut.
4. Let the blade run up to full speed before feeding the wood onto the blade. Do not force it – this will not result in a faster cut.
5. As the trailing edge of a larger sheet of material approaches the blade, the push stick will be pulled away from the blade. It has cleared the riving knife at the rear of the blade.
6. Keep both hands clear of the blade at all times.

SAWBENCH TO MITRE SAW
1. Plugging the saw.
2. Plugging the saw. Plug the guard by pulling the plunger knob on the blade guard to release the guard from the riving knife. Store the guard safely, together with the push stick, they will be essential when the flip-over saw is used as a sawbench.
3. Remove the rip fence and mitre fence, if fitted.
4. Pull the table release lever to the left, then lift the rear of the table and swing it right over until it locks into position at the front.
5. Partially lower the saw head, and disengage the lower end of rise and fall adjuster from its support at the rear of the sawhead. Swing the adjuster upwards until it clips into place in its newly upright position. Let the sawhead rise back into normal position.
6. Push the riving knife clamp knob to allow the riving knife to be tilted to the left and then swing up into the guard away from the blade. Tighten the clamp knob.

WORK AREA
1. Make sure that the area is clear and safe and that the ground is level and solid. There must be no tripping hazards, and adequate lighting. There should be no one near to you or other distractions.
2. Do not use this saw in the rain, or where it might get wet.
3. Do not use this saw where there is a danger of explosion. It will ignite fumes from petrol or gas cylinders.
4. Protect other people from the noise, dust and hazard. Warn others to keep away, put up signs, or barriers around your work area.
5. The following items of personal protective equipment (PPE) are the minimum which should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.
6. You must wear impact resistant goggles (EN166-B or BS2092 grade 1) whenever you use this saw bench.
7. This equipment is likely to cause noise levels up to 100 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for levels up to 100 dB(A).
8. Dust from softwood, hardwood and composite materials can be hazardous to health wear an appropriate dustmask (with a minimum of EN149 FFP3(s) protection) when you are cutting any material that causes dust.
9. Anybody who is working near to you will need to wear the same safety equipment. Make sure you have no loose or flapping clothing that could get caught in the saw.